



Issue: 1
 Issue Date: 100311

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	EH5001.01	COVER FOR GRILLE	16	EH5001.16	THERMOSTAT
2	EH5001.02	GRILLE	17	EH5001.17	CABLE GRIP
3	EH5001.03	HEATING ELEMENT 230V/300W	18	EH5001.18	RELAY
4	EH5001.04	INNER CASING	19	EH5001.19	RELAY SUPPORT
5	EH5001.05	TIME-DELAY THERMOSTAT	20	EH5001.20	MOTOR FAN
6	EH5001.06	THERMOSTAT	21	EH5001.21	MOTOR SUPPORT
7	EH5001.07	SENSOR	22	EH5001.22	MOTOR
8	EH5001.08	WIRE RING	23	EH5001.23	END PLUG
9	EH5001.09	OUTER CASING	24	EH5001.24	RUBBER FEET
10	EH5001.10	FRAME	25	EH5001.25	ADJUSTING KNOB
11	EH5001.11	HANDLE GRIP	26	EH5001.26	RIVET
12	EH5001.12	CONTROL BOX	27	EH5001.27	PLUG + WIRE
13	EH5001.13	SWITCH	28	EH5001.28	CONNECT PLATE
14	EH5001.14	KNOB	29	EH5001.29	HEATING ELEMENT SUPPORT
15	EH5001.15	SWITCH RING			

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.