




PARTS FOR:
DESK FAN 3-SPEED 12" 230V
 MODEL: **SFF12.V2**



Issue: 1
 Issue Date: 130315

ITEM	PART NO	DESCRIPTION
1	SFF12.V2-01	FRONT CAP
2	SFF12.V2-02	FRONT GRILLE
3	SFF12.V2-03	FAN BLADE
4	SFF12.V2-04	SCREW
5	SFF12.V2-05	MOTOR
6	SFF12.V2-06	SCREW
7	SFF12.V2-07	COVER
8	SFF12.V2-08	SCREW
9	SFF12.V2-09	CAPACITOR
10	SFF12.V2-10	CORD CLIP
12	SFF12.V2-12	REAR GRILLE

ITEM	PART NO	DESCRIPTION
13	SFF12.V2-13	SCREW
14	SFF12.V2-14	ROTARY KNOB
15	SFF12.V2-15	SWITCH COVER
16	SFF12.V2-16	SWITCH
17	SFF12.V2-17	SWITCH HOLDER
18	SFF12.V2-18	POWER CORD
19	SFF12.V2-19	SCREW
20	SFF12.V2-20	WASHER
21	SFF12.V2-21	ROTARY COVER, SIDE
22	SFF12.V2-22	RUBBER FOOT
23	SFF12.V2-23	BASE

