




**PARTS FOR:  
DESK/FLOOR FAN 3-SPEED 16" 230V  
MODEL: SFF16**



Issue: 1  
Issue Date: 130315

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	SFF16.01	FRONT CAP	13	SFF16.13	REAR BODY
2	SFF16.02	FRONT BODY	14	SFF16.14	SWITCH HOLDER
3	SFF16.03	SCREW FOR BLADE	15	SFF16.15	SWITCH
4	SFF16.04	FAN BLADE	16	SFF16.16	ROTARY KNOB
5	SFF16.05	SCREW	17	SFF16.17	SWITCH COVER
6	SFF16.06	MOTOR	18	SFF16.18	SCREW
7	SFF16.07	MOTOR BRACKET	19	SFF16.19	WIRE & PLUG
8	SFF16.08	SCREW	20	SFF16.20	BASE
9	SFF16.09	COVER	21	SFF16.21	RUBBER FOOT
10	SFF16.10	SCREW	22	SFF16.22	FOOT (LEFT AND RIGHT)
11	SFF16.11	CORD CLIP	23	SFF16.23	SCREW
12	SFF16.12	CAPACITOR	24	SFF16.24	WASHER