

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

1.1. GENERAL SAFETY

- ❑ **WARNING!** *Ensure Health & Safety, local authority and general workshop practice regulations are adhered to when using this equipment.*
- ✓ Familiarise yourself with the application and limitations of the curtain, as well as the specific potential hazards.
- ✓ Maintain the curtain in good condition (use an authorised service agent).
- ✓ Replace or repair damaged parts. *Use genuine parts only. Non-authorized parts may be dangerous and will invalidate the warranty.*
- ✓ Keep the work area clean and uncluttered and ensure there is adequate lighting.
- ✓ Keep the curtain clean for best and safest performance.
- ✓ Keep children and unauthorised persons away from the work area.
- x **DO NOT** use the curtain for any purpose other than that for which it is designed.
- x **DO NOT** use the curtain if any parts are damaged or missing as this may cause failure and/or personal injury.

2. INTRODUCTION & DIMENSIONS

2.1. Introduction



Supplied with amber welding screen to BS EN 1598. Suitable for use in workshops where the glare from welding and cutting may be a hazard to others. Supplied with two feet. Curtain and frame supplied flat packed. Assembles with ease.

2.2. Dimensions

Model:	SSP99.V2	SSP992	SSP993
Width:	1300mm	1800mm	2400mm
Height:	1750mm	1750mm	1750mm

3. ASSEMBLY

- 3.1. Take the two lower corner frame fittings (fig.2B) and insert them into the two feet. (fig.2E)
- 3.2. Insert the bottom horizontal bar (fig.2D) between the two feet (fig.2E), ensure that the sprung catches are seated correctly.
- 3.3. Insert the long vertical bars (fig.2C) in to the top of the corner fittings, ensure that the sprung catches are seated correctly.
- 3.4. Connect the two upper corner fittings (fig.2A) to the two vertical bars and then the remaining top bar (fig.2D) to them. Ensure that the sprung catches are seated correctly.
- 3.5. Stand the frame up and make sure the feet are square.
- 3.6. Take the Welding curtain and with it the correct way around secure it to the frame with the ties included.
- 3.7. The frame can be raised or lowered by loosening the thumb screw (fig.1) on the feet, when at the required height, tighten the thumb screw.



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

