

Tape down the mat edges to the ground surrounding the drain with the tape supplied.

If necessary, use some absorbent land booms to channel the flow of the water toward the DrainProTector
Carry out a safety check of the DrainProTector to ensure correct installation and not a safety hazard.

Regularly inspect the status and condition of the *DrainProTector* filter.
 If hydrocarbons please ensure you are using the Oil, Fuel and Silt *DrainProTector* version.

OIL, FUEL & SILT

